

AIDED MODE FOR THE FIRST STEP: INSTRUCTIONS TO FIND OUT THE TYPE OF BLUE&ME INSTALLED ON THE VEHICLE



The procedure shown on the following pages is useful to find the model and generation of Blue&Me for the vehicle. You need to follow all the steps sequentially for a correct completion of the procedure.

1. Unzip the BlueMeConfigurator.zip file downloaded into a suitable dedicated directory (e.g. c:\Blue&Me). At the end check that the following files are present:

Nome	Dimensione
ConfReader_conv.ARM920.CAB	23 KB
ConfReader_Lh.ARM926.CAB	19 KB
configuration	1 KB
install.inf	1 KB

2. Arrange a USB memory stick, with capacity at least 128 Mb, **formatting it in FAT32** to erase all previous data.

NOTE *It is advisable to use USB memory sticks with capacity below 256 Gb.*

3. Store on the USB memory stick, in the main folder, all previously downloaded files, making sure that they correspond. The updating **is NOT performed if the files are on the memory stick inside a folder.**

WARNING *before place the USB memory stick into the USB port of the vehicle, the mobile must be switched off.*

*The updating time depends on the vehicle and is less than one minute; **during this step, the buttons on the steering wheel should not be pressed***

4. With vehicle stopped and ignition key turned to **STOP**, place the USB memory stick in the USB port of the **Blue&Me™**.
5. Place the ignition key to **MAR-ON** position, WITHOUT STARTING THE VEHICLE. For a correct displaying of the warning messages on the display, press the "Mode" or "Menu" button to clean any previous warning message (e.g. door open).

WARNING *The USB memory stick should remain inserted also if the information "RESTARTING..." or "INSTALLATION IN PROGRESS"("INSTALLING") is displayed, followed by date and time.*

6. The instrument panel displays the message: "**UPDATING**" or "**UPDATE IN PROGRESS**" and the voice command "**update started**" is reproduced. If this does not occur, place the key to **STOP** position and to **MAR-ON** again. During update, the display shows some messages about the progress.
7. At the end of the procedure, the instrument panel display shows the message "**COMPLETE**" or "**UPDATE COMPLETED**" and the voice message "**update completed, remove the USB memory stick**".
8. Turn the ignition key to **STOP** position and take out the USB memory stick, containing the file BMConf.xml.
9. Insert the USB memory stick into the PC; go back to the **www.blueandme.net** site, section Support -> Download, click on the button "Fill in the filters in assisted mode", click on "Load File" and select the file BMConf.xml in the main folder of the USB memory stick.
10. The drop-down menus (Car model, Blue&Me generation, Blue&Me model, Language Change) are now configured according to the Blue&Me available on the car; you can download the SW update and relevant instructions by clicking on the button at the bottom of the page. **DO NOT modify the drop-down menus until the end of downloading.**

If this guide has not been useful, you could always refer to Customer Service, calling the freephone number shown on the sun visor or on the Owner Handbook of your car.