

CLUTCH PEDAL SWITCH

Switch (2) on the clutch pedal is connected to pin A61 of the engine control unit. The engine control unit uses the "clutch pedal operated" signal to distinguish between gear engaged and gear change conditions.

