



RHS Fuse and Relay Panel - B101



F34	Alarm / Remote Control
F38	ABI Door Lock
F40	RH Rear Demist
F41	Door Mirrors Demist
F45	CBE eng start sig + step ind.
F47	ABI Left Window
F48	ABI Right Window
F54	LH Rear Demist
F56	Extra Air Con
F57	Supplementary Htr Fan
F58	Webasto Timer
F59	Food Box ?
F60	Alarm Blinker
F61	Webasto Unit
F63	Beacon
F64	Rear Current Skt
F65	Current Skt Special
F66	
F67	
F68	
F69	
F80	
F81	
F82	

Notes.

1. Fuse F45 was designated for heated seat option. Terminal & 5A fuse added.
2. Step connection was at T24/86 socket pin, & F31 on CFB was increased to 25A.
3. Alarm fob control repeat relay wired out, and operated from alarm fob centre button.
4. Items coloured light yellow, not fitted / used.



View looking into
relay socket

AB 07/03/23