


NUOVA BRAVO 1.4 16v GLOVE COMPARTMENT IN DASHBOARD - ARRANGE 7040A18

[back to RH UPPER MIXED AIR TEMPERATURE SENSOR - R.R. FOLLOWING ELECTRICAL CIRCUIT CHECK](#)



Removing ([Refitting](#))

- Op. 7040A14 FLAP FOR GLOVE COMPARTMENT IN DASHBOARD - R.R.**
- Op. 7040G22 BULB HOLDER/SWITCH FOR COMPARTMENT LIGHT IN DASHBOARD - R.R.**
- Op. 5570T49 BLUETOOTH ELECTRONIC CONTROL UNIT - R.R.**
- Op. 7040A45 RIGHT DASHBOARD SIDE TRIM - R.R.**
- Op. 7040L37 GEAR LEVER TRIM - R.R.**
- Op. 7040L73 BOTTLE-HOLDER/ASHTRAY ON REAR TUNNEL TRIM - R.R.**
- Op. 7040L70 TUNNEL COVER REAR TRIM - R.R.**
- Op. 7040L20 TUNNEL COVER - R.R.**
- Op. 7040A65 CONSOLE SIDE CLOSING (ONE) - R.R.**

1. Undo bolt (1a) for flap striker (1b).
 2. Unscrew the compartment retaining bolts.
 3. Remove the compartment.
- If necessary remove the flap travel limiter.

Op. 7040A16 LIMITER FOR FLAP FOR GLOVE COMPARTMENT IN DASHBOARD - R.R.

Refitting ([Removing](#))

- Check that the compartment is not damaged.

Op. 7040A16 LIMITER FOR FLAP FOR GLOVE COMPARTMENT IN DASHBOARD - R.R.

- Position the compartment.
- Tighten the compartment retaining bolts.
- Tighten the bolt for the flap closure striker.

Op. 7040A65 CONSOLE SIDE CLOSING (ONE) - R.R.

Op. 7040L20 TUNNEL COVER - R.R.

Op. 7040L70 TUNNEL COVER REAR TRIM - R.R.

Op. 7040L73 BOTTLE-HOLDER/ASHTRAY ON REAR TUNNEL TRIM - R.R.

Op. 7040L37 GEAR LEVER TRIM - R.R.

Op. 7040A45 RIGHT DASHBOARD SIDE TRIM - R.R.

Op. 5570T49 BLUETOOTH ELECTRONIC CONTROL UNIT - R.R.

Op. 7040G22 BULB HOLDER/SWITCH FOR COMPARTMENT LIGHT IN DASHBOARD - R.R.

Op. 7040A14 FLAP FOR GLOVE COMPARTMENT IN DASHBOARD - R.R.