


I don't get this screen as shown in the user guide.....

On the next screen select the lowest possible value for "Latency Timer"



On all my computers the screen jumps straight to this:

