

http://aftersales.fiat.com/eLumData/EN/00/319_PANDA/00_319_PANDA_603.99.249_EN_01_09.12_L_LG/00 - Windows Internet Explorer

http://aftersales.fiat.com/eLumData/EN/00/319_PANDA/00_319_PANDA_603.99.249_EN_01_09.12_L_LG/00_319_PANDA_603.99.249_EN_01_09.12_L_LG/00

Google

File Edit Go To Favorites Help

Safe Web

Identity Safe

Favorites

http://aftersales.fiat.com/eLumData/E...

92 / 284

103%

Find

Search

Looking For:
laser in the current document

Results:
1 documents with 10 instances

New Search

Results:

untitled

LASER SENS

a laser senso

The laser sen

the laser sen

the laser sen

laser. WARN

The laser be

☒ Collapse file paths

[Use Basic Search](#)

[Save and View this PDF](#)

[Find a word in the](#)

GETTING TO KNOW YOUR CAR

SAFETY

STARTING AND DRIVING

WARNING LIGHTS AND MESSAGES

IN AN EMERGENCY

SERVICING AND MAINTENANCE

TECHNICAL SPECIFICATIONS

INDEX

Versions equipped with Dualogic automatic transmission (for versions/markets, where provided): at the end of braking the last gear stored remains engaged.

IMPORTANT Both on versions equipped with manual gearbox and on those with Dualogic automatic transmission (for versions/markets, where provided), after the car is stopped the brake calipers may be stuck for about 2 seconds for safety reasons. Make sure you press the brake pedal if the car moves slightly forwards.

IMPORTANT The system does **NOT** activate engaging the reverse. The system does **NOT** activate if the front seat belts are not fastened.

LASER SENSOR

The system includes a laser sensor, located in the upper part of the windscreen . fig. 73




fig. 73 FOW0015

IMPORTANT



WARNING
The system is an aid for the driver who must never reduce attention while driving. The responsibility always rests with the driver, who must take into account the traffic conditions for driving in complete safety. The driver must always maintain a safe distance from the vehicle in front.



WARNING
If the driver depresses the brake pedal fully or carries out a fast steering during system operation, the automatic braking function may stop (e.g. to allow a possible manoeuvre to avoid the obstacle).



The laser sensor may have limited or absent operation due to weather conditions such as: heavy rain, hail, thick fog, heavy snow, formation of ice layers on the windscreen.

Unknown Zone | Protected Mode: On