

Diagram 10: Most models - Fuel Level Gauge and Reserve Warning Light - Low Brake Fluid Level Warning Light - Handbrake Warning Light - Water Temperature Gauge - Brake Pad Wear Warning Light - Low Engine Oil Pressure Warning Light - Water In Fuel Warning Light - Clock - Rev. Counter - Speedometer - Engine Oil Pressure Gauge
 #Not all models *Versions 1242 - 1697 TD SX only **TD versions only ▲ Variant connections for TD versions




Diagram 11: All models without air conditioner - Engine Cooling System - Car Interior Ventilation - Water Temperature Gauge - C gas Lighter
 * and ** - Certain models only